

Module Inspect 3D



<WRAP group> <WRAP threequarters column>


Program version	BASIC	2D PRO	3D PRO	LAB	OMS
Availability					

Module Inspect 3D provides different types of distance and area measurements on any 3D data set, both individually and in relation to individually aligned reference objects. The results can be displayed numerically and graphically and exported. The result of the processing must be saved as a finding of the results for further use.

First Steps

1. Select | adjust reference
2. Set up visibility
3. Select type of measurement
4. Display | export results
5. Save modified data set as finding

Module user interface



Links



From:
<http://onyxwiki.net/> - [OnyxCeph³™ Wiki]

Permanent link:
http://onyxwiki.net/doku.php?id=en:inspect_3d&rev=1644236239

Last update: **2022/02/07 13:17**

