

Icon Button [90° Rotation]

Icon	Action
	90° Rotation

By icon button [90° Rotation] the view direction for the 3D scene in a 3D view (in single panel mode) can be rotated/tilt in 90° steps click-by-click always parallel to the object coordinate system axes. In case a multi panel view is active for the 3D view window, icon button [90° Rotation] is deactive. See also [#4434 Extended 3D Standard View](#).

From:

<http://www.onyxwiki.net/> - [OnyxCeph³™ Wiki]

Permanent link:

http://www.onyxwiki.net/doku.php?id=en:ic_001

Last update: **2017/10/22 13:50**

